Table of Contents

Chapter 1: Getting Started 1–1

Introduction 1–2

Conventions Used 1–3

Product Overview 1–4

Agency Approvals 1–5

Part Number Key 1–5

Product Label Examples: 1–6

Serial Number and Date Code formats: 1–6

Quick Start Steps 1–7

Step 1 – Unpack and Inspect 1–7
Step 2 – Install Optional Hardware Accessories 1–8
Step 3 – Become Familiar with Available Communication Ports 1–9
Step 4 – Install C-more Micro-Graphic Panel 1–10
Step 5 – Install the Programming Software and Develop a Project 1–11
Step 6 – Connect C-more Micro-Graphic Panel to Computer 1–12
Step 7 – Provide Power to the C-more Micro-Graphic Panel 1–13
Step 8 – Accessing the C-more Micro-Graphic Panel Setup Screens 1–14
Step 9 – Choose C-more Micro-Graphic Panel to PLC Protocol & Cables 1–15
Step 10 – Connect C-more Micro-Graphic Panel to PLC 1–16

Chapter 2: Specifications 2–1

Available Models 2–2

Model Specifications 2–4

Panel Dimensions (all models) 2–6

Communications Ports 2–7

Chemical Compatibility 2–8

Chapter 3: Accessories 3–1

Accessories 3–2

***C-more* Micro-Graphic Programming Software** 3–3

USB to RS-232 Programming Cable Assembly 3–7

8-Button Keypad Bezel 3–9

20-button Keypad Bezel 3–12

DC Power Adapter 3–15

Serial Port with DC Power Adapter 3–19

Clear Screen Overlay 3–22

Chapter 4: Installation and Wiring 4–1

Safety Guidelines 4–2

Introduction 4–3

Panel Cutout Dimensions (all models) 4–4

Wiring Guidelines 4–5

Chapter 5: System Setup Screens 5–1

Introduction 5–2

Accessing the System Setup Screens 5–3

System Setup Screens Flowchart 5–4

Setup Menu 5–5

Information Menu 5–6

Memory 5–6

Protocol 5–6

Extensions 5–6

Versions 5–6

Setting Menu 5–7

LCD Contrast 5–7

Backlight 5–8

Beep 5–10

Calibration 5–11

Clear User Memory 5–12
Reset to Factory Default 5–12
Hourglass 5-13
Test Menu 5–14
Serial Port1 - Loop Back Test 5–14
Serial Port2 - Loop Back Test 5–15
PLC Enquiry Test 5–16
Buzzer Test 5–16
Touch Panel Test 5–17
Exit 5–17

Chapter 6: PLC Communications 6–1

Introduction 6–2
Available PLC Protocols 6–2
C-more Micro-Graphic Built-in Port 1 6–3
C-more Micro-Graphic Optional EA-MG-SP1 Port 2 6–4
DirectLOGIC PLCs Password Protection 6–5
PLC Compatibility and Connection Charts 6–5
AutomationDirect Controllers 6–5
RS-422A/RS-485A Communications 6–5
Allen-Bradley: 6–6
GE, Mitsubishi, Omron, Modicon and Siemens: 6–6
How to use the PLC Compatibility and Connection Charts 6–7
Example: 6–7
Available Purchased Cables 6–22
Available Purchased Cables – Wiring Diagrams 6–24
User Constructed Cables – Wiring Diagrams 6–34
RS-422A/RS-485A Multi-Drop Wiring Diagram Examples 6–44

Chapter 7: Maintenance 7–1

Project Backup 7–2
Check Operating Environment 7–2

Check Operating Voltage 7–2
Check Transmit and Receive Indicators 7–3
Check Physical Conditions 7–3
Run Tests under the System Setup Screens 7–4
Check Settings under the System Setup Screens 7–5
Cleaning the Display Screen 7–5
Check Project Functionality 7–6
Checks from the C-more Micro-Graphic Programming Software 7–6

Chapter 8: Troubleshooting 8–1
***C-more* Micro-Graphic Panel does not Power up** 8–2
Display is Blank 8–2
Display is Dim 8–3
No User Program 8–3
Lost Firmware – Red 'Update Mode' Screen Displayed 8–4
No Communications between Panel and PC 8–5
No Communications between Panel and PLC 8–7
Panel & PLC Error Codes 8–8
***C-more* Micro-Graphic Panel Runtime Errors** 8–9
Electrical Noise Problems 8–10

Chapter 9: Replacement Parts 9–1
Replacement Parts Overview 9–2
Replacement Parts 9–2
Panel Mounting Clips – EA-MG-S3ML-BRK 9–2
Panel Gasket – EA-MG-S3ML-GSK 9–2
8-Button Keypad Bezel Mounting Clips – EA-MG-BZ1-BRK 9–2
8-Button Keypad Bezel Gasket – EA-MG-BZ1-GSK 9–2
20-Button Keypad Bezel Mounting Clips – EA-MG-BZ2-BRK 9–3
20-Button Keypad Bezel Gasket – EA-MG-BZ2-GSK 9–3
DC Power Connector – EA-MG-DC-CON 9–3
Function Keys Label Inserts – EA-MG-S3ML-FKL 9–3
Customizing the Function Keys Label Insert 9–4

Appendix A: PLC Protocol Error Codes A–1

Introduction A–2

C-more Micro-Graphic Panel Error Code Table A–3

Modbus Protocols Error Code P499 Explanation A–4

AutomationDirect CLICK A–4

AutomationDirect DirectLOGIC - Modbus (Koyo) A–4

Modicon Modbus RTU A–4

Entivity Modbus RTU A–4

Productivity3000 Error Code P499 Explanation A–5

Do-more Error Code P499 Explanation A–6

DirectLOGIC Error Code P499 Explanation A–7

DirectLOGIC – K-Sequence PLC Error Code Table A–7

DirectLOGIC – DirectNET PLC Error Codes A–7

Allen-Bradley Error Code P499 Explanation A–8

Allen-Bradley DF1 Protocol – PLC Error Code Tables A–9

Allen-Bradley DH485 Protocol – PLC Error Code Tables A–11

GE Error Code P499 Explanation A–13

GE SNPX Protocol – PLC Error Code Tables A–14

Mitsubishi FX Protocol – PLC Error Codes A–23

Mitsubishi Q / QnA Series – PLC Error Codes A–23

Omron Error Code P499 Explanation A–25

Omron Host Link Protocol – PLC Error Code Table A–26

Omron FINS Protocol – PLC Error Code Table A–27

Siemens Error Code P499 Explanation A–30

Siemens PPI Protocol – PLC Error Code Table A–31

Appendix B: Micro-Graphic Panel Runtime Errors B–1

Introduction B–2

Runtime Errors B–2

Index